OMROD

Product Guide

OMRON Corporation 1148338-5B

Thank you for purchasing the SYSMAC Gateway Runtime (WS02-SGWC1).

Before Use

Components

This package includes the following components. Please check that all the components are included in the package.

About non-bundled handling to the product of manuals

The manuals such as the Installation Guide are not bundled in this product by the viewpoint of the global environment protection. The manual below is stored on the SYSMAC Gateway Runtime installation disk (CD-ROM) as PDF file, and can be referred to from the start menu after SYSMAC Gateway Runtime installation procedure.

- PDF files
 SYSMAC Gateway Installation Guide
- Online help (.chm files)
 SYSMAC Gateway Online Help
 FinsGateway Online Help

Installation/Uninstallation Procedure

For a detailed installation/uninstallation procedures, refer to the SYSMAC Gateway Runtime Installation Guide on the CD-ROM.

Precautions when Installing the SYSMAC Gateway

 The SYSMAC Gateway Runtime cannot be installed from a network drive, such as a CD drive or hard disk drive shared on a network. Always install the SYSMAC Gateway from a CD drive on the computer onto which the software is being installed.

User Registration Procedure

After confirmation of "Software License Agreement" perform user registration before using the SYSMAC Gateway Runtime.

Online User Registration (Internet Connection Required)

Access our website at the URL below for the online user registration. A user ID will be issued immediately. https://www.omron-cxone.com/license

Enter the information required for user registration according to the site windows.

After completion of registration, registration confirmation will be sent to the email address input during the registration procedure.

Note: • Use the product key and license number given on the Software License Agreement/ User Registration Card provided with the SYSMAC Gateway.

• Do not register more than once. For example, if you have returned the card, do not register online.

Using the User Registration Postcard

Enter the required information on the User Registration Postcard provided with the SYSMAC Gateway Runtime and send the card.