# OMRON ₩ZFX-XPM

パネルマウントアダプタ

# 取扱説明書

このたびは、本製品をお買い上げいただきまして、まことにあり がとうございます。ご使用に際しては、次の内容をお守りください。 ・電気の知識を有する専門家が扱ってください。 ・この取扱説明書をよくお読みになり、十分にご理解のうえ、正 しくご使用ください。 ・この取扱説明書はいつでも参照できるように大切に保管くださ い。



# 安全上の要点

以下に示すような項目は安全を確保する上で必要なこと ですので必ず守ってください。

- 1. 引火性、爆発性ガスの環境では使用しないでください。
- 2. この製品は分解したり、修理、改造をしないでください。
- ロック機構のあるものは必ずロックしていることを確認してからご使用ください。
- 4. 廃棄するときは、産業廃棄物として処理してください。

## 使用上の注意

- 着脱について パネルマウントアダプタの着脱は、必ずコントローラの電 源を切った状態で行ってください。電源 ON のまま行 うと、故障の原因になります。
- 清掃について シンナー、ベンゼン、アセトン、灯油類は使用しないで ください。
- 設置に関するご注意 取付けねじは、規定のトルクで締め付けてください。 推奨締付けトルク:1.2N・m

## ■材質/性能

| 項目    形式 | 形 ZFX-XPM  |
|----------|--|
| 適用コントローラ | 形 ZFX シリーズ   |
| 振動(耐久)   | 振動周波数:10 ~ 150Hz<br>片振幅:0.35mm<br>X/Y/Z 方向各 8 分 10 回 |
| 衝撃(耐久)   | 150m/s <sup>2</sup> 6 方向<br>各 3 回(上下、左右、前後)          |
| 材質       | ポリカーボネイト(PC)、他                                       |
| 質量(梱包状態) | 約 100g   |
| 付属品      | 取付金具 4個<br>取扱説明書(本紙)                                 |

### ■取付方法

①長いマウントアダプタをコントローラの穴(4箇所)に取付ける

②短いマウントアダプタを長いマウントアダプタに取付ける ③マウントアダプタを取付けたコントローラを、盤面の点前 から取付ける

パネルマウントアダプタ



(単位:mm)

④長いマウントアダプタの穴(2箇所)に取付金具のフックを引っかけて、ネジを締め込む 締付けトルク:1.2N・m



⑤コントローラが盤面に固定されていることを確認する

### ご使用に際してのご承諾事項

- ①安全を確保する目的で直接的または間接的に人体を検出する用途に、本製品を使用しないでください。同用途には、当社センサカタログに掲載している安全センサをご使用ください。
- \*上記は適合用途の条件の一部です。当社のベスト、総合カタログ・データシート等最新版 のカタログ、マニュアルに記載の保証・免責事項の内容をよく読んでご使用ください。

#### オムロン株式会社 インダストリアルオートメーションビジネスカンパニー

| ●お問い合わせ先   |
|--|
| <sup>nxyqt#</sup> +te <sup>2y</sup> 0120-919-066   |
| 携帯電話・PHSなどではご利用いただけませんので、その場合は下記電話番号へおかけください。  |
| 電話 055-982-5015 (通話料がかかります)  |
| 〔技術のお問い合わせ時間〕<br>■営業時間:8:00~21:00<br>■営 業日 :365日   |
| ■上記フリーコール以外のFAシステム機器の技術窓口:   |
| 電話 055-977-6389 (通話料がかかります)  |
| 〔営業のお問い合わせ時間〕<br>■営業時間:9:00~12:00/13:00~17:30 (土・日・祝祭日は休業)<br>■営 業 日:土・日・祝祭日/春期・夏期・年末年始休暇を除く |
| ●FAXによるお問い合わせは下記をご利用ください。<br>カスタマサポートセンタ お客様相談室 FAX 055-982-5051                             |
| ●その他のお問い合わせ先<br>納期・価格・修理・サンブル・仕様書は貴社のお取引先、<br>または貴社担当オムロン営業員にご相談ください。                        |
| B@ 2009年10月  |



# OMRON Model ZFX-XPM

Panel Mount Adapter

# **INSTRUCTION SHEET**

Thank you for selecting OMRON product. This sheet primarily describes precautions required in installing and operating the product.

Before operating the product, read the sheet thoroughly to acquire sufficient knowledge of the product. For your convenience, keep the sheet at your disposal.



© OMRON Corporation 2007 All Rights Reserved.

### PRECAUTIONS FOR SAFE USE

Please observe the following precautions for safe use of the product:

- 1. Do not use the product in environments where it can be exposed to inflammable/explosive gas.
- 2. Do not disassemble, repair or modify this product.
- 3. Be sure to make sure that locking mechanisms are locked before use.
- 4. Dispose of this product as industrial waste.

### PRECAUTIONS FOR CORRECT USE

1. Installation/Removal

Before installing/removing the Panel Mount Adapter, make sure that the Controller is turned OFF. The Panel Mount Adapter may break down if it is installed or removed while the power is ON.

2. Cleaning

Do not use paint thinner, benzene, acetone, or kerosene for cleaning.

3. Installation Precautions

Tighter mounting screws at the torque specified. Recommended screw tightening torque:1.2N·m

### Specifications

| Item Model                            | ZFX-XPM  |
|---------------------------------------|--|
| Applicable controller                 | ZFX Series   |
| Vibration resistance<br>(destructive) | Vibrational frequency:10 to 150 Hz<br>half amplitude:0.35-mm<br>10 times each in X,Y and Z<br>directions for 8 min |
| Shock resistance<br>(destructive)     | 150 m/s <sup>2</sup> in six directions<br>3 times each in six directions<br>(up/down, left/right,forward/backward) |
| Materials                             | Polycarbonate (PC), etc.   |
| Weight (packed state)                 | Approx. 100 g  |
| Accessories                           | Mounting bracket (4)<br>Instruction sheet  |

### Mounting

- ①Install the long Panel Mount Adapters on the four holes on the Controller.
- <sup>(2)</sup>Install the short Panel Mount Adapters on the two holes on the long Panel Mount Adapter.
- ③Install the Controller with Mount Adapters attached onto the panel from the front.

Panel mount adapters



٦₫

(60.5)

- (4) Hook the hooks of the mounting bracket onto the two holes of the longer Mount Adapters and tighten the screws.
- Tightening torque:1.2N · m



Mounting bracket

<sup>5</sup>Make sure that the Controller are firmly fixed on the panel.

#### Suitability for Use

THE PRODUCTS CONTAINED IN THIS SHEET ARE NOT SAFETY RATED. THEY ARE NOT DESIGNED OR RATED FOR ENSURING SAFETY OF PERSONS, AND SHOULD NOT BE RELIED UPON AS A SAFETY COMPONENT OR PROTECTIVE DEVICE FOR SUCH PURPOSES. Please refer to separate catalogs for OMRON's safety rated products.

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of the products in the customers application or use of the product.

Take all necessary steps to determine the suitability of the product for the systems, machines, and equipment with which it will be used. Know and observe all prohibitions of use applicable to this product.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS. AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM. See also Product catalog for Warranty and Limitation of Liability.

| _ |   |
|---|---|
|   | EUROPE<br>OMRON EUROPE B. V. Sensor Business Unit<br>Carl-Benz Str.4, D-71154 Nufringen Germany<br>Phone:49-7032-811-0 Fax: 49-7032-811-199   |
| ľ | NORTH AMERICA<br>OMRON ELECTRONICS LLC<br>One Commerce Drive Schaumburg,IL 60173-5302 U.S.A.<br>Phone:1-847-843-7900 Fax: 1-847-843-7787  |
|   | ASIA-PACIFIC<br>OMRON ASIA PACIFIC PTE. LTD.<br>No. 438A Alexandra Road #05-05-08(Lobby 2),<br>Alexandra Technopark, Singapore 119967<br>Phone: 65-6835-3011 Fax: 65-6835-2711              |
|   | CHINA<br>OMRON(CHINA) CO., LTD.<br>Room 2211, Bank of China Tower,<br>200 Yin Cheng Zhong Rond,<br>PuDong New Area, Shanghai, 200120, China<br>Phone: 86-21-5037-2222, Fax: 86-21-5037-2200 |
| 0 | DMRON Corporation   |
| D | () OCT, 2009  |

### Dimensions



Panel cutout dimensions

